

Thank you for selecting our products...products which have been the benchmarks of fine quality for years. To help ensure that the installation process will proceed smoothly, please read these instructions carefully before you begin. Also, review the recommended tools and materials list; carefully unpack and examine your new plumbing fixture.

ALL INSTALLATION PROCEDURES MUST COMPLY IN STRICT ACCORDANCE WITH APPLICABLE LOCAL PLUMBING AND BUILDING CODES

RECOMMENDED TOOLS AND MATERIALS



Putty Knife




Adjustable Wrench



Level



Plumber's Putty or Caulking




Hacksaw



Tape Measure




Pipe Wrench



Drill



Channel Lock Pliers



Phillips Screwdriver




Regular Screwdriver

ROUGHING-IN DIMENSIONS

Dimensioning diagrams are provided for each model.
Note: dimensions are nominal and may vary within the range of manufacturing tolerances.

Unit: mm



- Fig.1 for installing with semi-pedestal(TF-0755)
- Fig.2 for installing with full-pedestal(TF-0765)




Fig. 1




Fig. 2

A. Installing of semi-pedestal lavatory

1


Preparation for semi-pedestal lavatory installation

Place the lavatory and semi-pedestal on the installing position, mark lavatory and semi-pedestal screw locations through the mounting holes.





2

Punching




Remove lavatory and semi-pedestal from installed position. Drill pilot holes for lavatory and semi-pedestal anchor screws or lag bolts.

Note: When install semi-pedestal lavatory, use a drill of Ø10mm to punch the mounting hole for installing L-shape bracket.




3

Install the stop valve




3.1 Install the inlet valve



3.2 Install "L" shape bracket.


4

Following manufacturer's instructions, install faucet and drain assembly (not included). Be certain to apply a bead of sealing putty on the underside of the drain (area "A") in order to ensure a watertight seal between the lavatory and drain. Remove excess putty after installing drain on lavatory.





5

Return the fitted lavatory to the installed position. Connect trap to drain assembly hand tight to check alignment. It may be necessary to cut off part of the tailpiece (area "B") or part of the horizontal leg of the trap (area "C").



6


Fix lavatory to wall as shown. Install washers and hand tighten nuts or lag bolts. Level and square the unit. Connect hot and cold supply lines to the shut-off valves. Tighten trap joints for watertight assembly.



7


Install semi-pedestal

Install semi-pedestal under the lavatory. The top rim of semi-pedestal attach under of lavatory. Fix the bolts by using the screw as picture shown.



8

Check the level after installation.



9

Open the water supply valve to check the assembly for any leak, if no leak was found, apply silicone sealant around the lavatory. (Silicone not included in the packaging)



B. Installing of pedestal lavatory

1

Place lavatory and pedestal on the installed position. Mark lavatory and pedestal screw locations through the mounting holes.



2



Please refer to step 2, 3.1, 4, 5 of semi-pedestal lavatory installation (part A) to install the lavatory and faucet.



3

3.1 Place lavatory and pedestal on the installed position.



3.2 Fix lavatory to wall as shown. Install washers and hand tighten nuts or lag bolts. Level and square the unit. Connect hot and cold supply lines to the shut-off valves. Tighten trap joints for watertight assembly.



4**Install pedestal screws****5**

Please refer to step 8,9 of semi-pedestal lavatory installation (part A) to check the level.

C. Installing of wall-hung lavatory

Note: Please refer to semi-pedestal lavatory installation step (part A) to install wall-hung lavatory.

CARE AND MAINTENANCE

Do not use harsh abrasives or caustic cleaners to clean fixture surface. A mild detergent, warm water, and a soft cloth will remove normal dirt and soap accumulations from fittings and surfaces. Rinse thoroughly after cleaning and polish with a soft dry cloth to restore original luster of material.

AMERICAN STANDARD LIMITED WARRANTY

If inspection of this products, within one year warranty after purchasing, confirms that its defective under normal use in material or workmanship. We will repair or, at its option exchange the product of a similar model.

The warranty does not cover the following:

1. None any documentary evidences to show the period of warranty such as receipt, warranty card, etc.
2. Consequential or incidental damages.
3. Defects or damages arising from shipping, installation, alternation, accidents, misuse or lack of proper maintenance.
4. Postage or shipping costs incurred in returning products for repair or replacement under this warranty and any labor or other costs or removal or installation of products under this warranty.
5. A product discontinuous.

American Standard B&K (Thailand) Public Company Limited

1/6 Moo 1, Phaholyothin Road, KM. 32,

Klong-neung, klong Laung, Pathumthani 12120 Tel.(662) 901-4455 Fax, (662) 901-4493

www.ameicanstandard.co.th



Bangkok : 1st Bangkok Business Center Building, 29 Sukhumvit 63 (Ekamai), Bangkok 10110
Tel. (662) 714-2433, Fax. (662) 714-2599

Chiangmai : 162/6-7 Chiangmai-Lumpang Road, Pa Tun, Amphoe Mueng, Chiangmai 50300
Tel. (665) 321-8047-8, Fax.(665) 321-8342

Phuket : 108/79 Chalermphakieat Road, Rassada, Amphoe Mueng, Phuket
Tel. (667) 626-1636-7, Fax. (667) 626-1638

Pattaya : 240/18-19 Moo 6, Sukhumvit Road, Naklua, Banglamong, Chonburi 20150
Tel. (038) 716-710,716-820, Fax. (038) 716-663